## **LED Linear Pendant**

LP73536

INSTALLATION SHEET

## START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area.
- Wear gloves at all times during this installation.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-855-855-8926

## Please Note:

- This Kuzco LED fixtures comes with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) or TRIAC type of dimmer is required.
- 120V input

- 1. Remove the fixture from its original packaging
- 2. Separate the mounting plate (1c) from the canopy (2a) by removing the canopy screws (2b)
- **3.** Attach the mounting plate (1c) to the electrical junction box (1a) using junction box screws provided (1e) in the hardware package
- **4.** Make proper electrical connections (**black** to **hot** "L", **white** to **neutral** "N", **ground** to "**GND**") with wire nuts (**1b**) provided in hardware package and place driver (**4a**) in canopy (**2a**)
- **5.** Attach canopy **(2a)** to mounting plate **(1c)** with canopy screws **(2b)**
- **6.** Mark and install ceiling anchors (3b) with screw (3a), opening on ceiling anchor (3b) facing towards canopy (2a). Ideal distance between ceiling anchors (3b) is 35-7/16"
- Place wire onto pulley (3g), insert into ceiling anchor (3b) and secure with screw (3f)
- **8.** Fine tone wire length if necessary, by push and hold wire gripper (2g) and then adjust wire to desired length
- **9.** Tilt fixture plate (5a) to desired position



