

## ASSEMBLY INSTRUCTIONS

## Cubist Medium Chandelier


Item # KW 5021

### NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

### TOOLS REQUIRED (NOT INCLUDED):

Phillips Screwdriver	Slotted Screwdriver	Chain Pliers
Slip Joint Pliers	Measuring Tape	Wire Cutters
Wire Strippers		



- Carefully remove all parts from the box. Place on a clean, soft surface.
- Remove collar loop (D) from chain (P) by removing quick link (G).
- Install mounting plate (B) to the junction box and secure with mounting screws (C).
- Secure collar loop (D) to mounting plate (B) using pliers to tighten locknut.
- Install canopy (E) to collar loop (D) and secure with collar ring (F).
- Install light bulbs into the sockets.
- Install glass panels (L) & (O) to metal frame (K) and secure with rubber washers (M) and screws (N).  
**NOTE:** Do not overtighten otherwise glass could become damaged.
- Determine desired overall length, and amount of chain (P) needed. Shorten chain using chain pliers. (Keep extra chain)
- Attach chain (P) to collar loop (D) and fixture loop (H) using quick links (G). Secure quick links (G).
- Thread fixture wire and ground wire through chain (P).  
**NOTE:** When you reach collar loop (D), ensure there is no tension on the wires. Cut excess wires, being sure to leave about 12" to reach the junction box.
- Separate two sides of molded wire, and strip insulation on each 5/8".

