

LIVING DISTRICT

Collection: Resolute


Installation manual for:
LD4061D32 L31.9"W11"H10.8"L4

Installation instructions:

1. Using the screw (P5) secure the mounting bracket (P4) to the junction box.
2. Connect the chain (P11) to canopy plate (P7) then hanging the lamp body.
3. Power cord pass through the chain (P11), canopy plate (P7) and clasp (P6).
4. Black wire from ceiling (junction box) attaches to "L" wire from the fixture.
5. White wire from ceiling (junction box) attaches to "N" wire from the fixture.
6. "E" wire from the fixture is attached to the mounting bracket and an additional "E" wire from the mounting bracket must be secured to the junction box.
7. M5 screw (P3) pass through the holes in canopy plate and tighten by nut (P9).
8. Install the bulb (not included) in lamp holder (P18).

The end!

PARTS LIST



part	picture	Description	Qty	Check list
P1		L5.9" Mounting bracket	1	
P2		M5 Nut	2	
P3		M5 Screw	2	
P4		Ø4.0" Mounting bracket	1	
P5		5/32-32 Screw	2	
P6		Clasp	1	
P7		L11.8" Canopy plat	1	
P8		Loop	4	
P9		Nut	2	
P10		Quick link	4	
P11		L59"CHAIN04	2	
P12		Power Cord 6.5' SPT-1 18# black	1	
P13		M4 Screw	2	
P14		L16.5"Metal arm	1	
P15		0.8"*0.8" Sealing cover	2	
P16		L31.9" Lampshade	1	
P17		E26 Lamp cup	4	
P18		E26 Lamp holder	4	

"L" = Hot wire
"N" = Neutral wire
"E" = Ground wire