

# H457701S, H457701L SASHA PENDANT

## ASSEMBLY AND MOUNTING INSTRUCTIONS

#### **GENERAL**

- WARNING-DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. TURN OFF THE ENTIRE ELECTRICAL CIRCUIT TO WHICH THE LIGHTING FIXTURE IS ATTACHED
- INSTALLATION AND MAINTENANCE OF THIS FIXTURE SHOULD BE COMPLETED BY A LICENSED ELECTRICAN
- FAILURE TO INSTALL FIXTURE CORRECTLY COULD RESULT IN SERIOUS INJURY OR DEATH
- READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION.

- IF AN EXISTING FIXTURE IS BEING REPLACED, REMOVE IT AND NOTE TO WHICH WIRE IN THE OUTLET BOX THE ORIGINAL FIXTURE WAS ATTACHED.
- BEFORE DISCARDING THE CARTON DOUBLE CHECK THE PACKAGING TO MAKE SURE ALL PARTS HAVE BEEN FOUND.
- THIS FIXTURE WAS DESIGNED TO BE MOUNTED TO AN OCTAGON OUTLET BOX. THE BOX MUST BE SECURELY MOUNTED TO THE STRUCTURE OF THE BUILDING.

#### **INSTALLATION**

STEP 1.	Pull the wires out from the outlet box, and install mounting plate onto the outlet box using the (2) mounting screws.	STEP 8.	Repeat the previous step with the hot (black wires). Make sure there are no exposed wires or strands that could
STEP 2.	Thread the wire through stem and twist tightly onto body.		cause a dangerous short circuit.
STEP 3.	Choose the length of the chain you need. (to remove excess chain section, use pliers to bend link open)		FAILURE TO CONNECT THE APPROPRIATE WIRES CORRECTLY COULD RESULT IN SEROIUS INJURY OR
STEP 4.	Thread the fixture wire and the ground wire through the		DEATH!
	chain, collar, canopy, and top loop. Connect the chain to	STEP 9.	Carefully place connections back into the outlet box.
	the loop and top loop.	STEP 10.	Attach the canopy to the mounting plate by inserting the
STEP 5.	Trim excess wire to min 6" beyond stem, strip to 5/8" and		top loop, then secure it with ring.
	twist.	STEP 11.	Lift the glass to the glass fitter then secure with thumb
STEP 6.	Fasten bare ground wire to ground wire from the wall outlet		screws.
	box (usually green or copper color) or connect ground wire	STEP 12.	Life the shade to the socket then secure with socket ring.
	to green screw on the mounting plate.	STEP 13.	Install the lamps. The fixture is rated for 15-watt LED type
STEP 7.	Connect the neutral (white) fixture wire coming from the		A lamp.
	fixture base to neutral (usually white) outlet wire. Fasten		DO NOT EXCEED RECOMMENDED WATTAGE!
	both wires together with a plastic wire nut and tightly wrap the wire nut with electrical tape.	STEP 14.	Restore power to the circuit at breaker or fuse box.

#### **DIMMING**

The fixture can be controlled by a wall dimming device. Only use triac /electronic dimmer. Make sure carton is marked for use with LED compact fluorescent-incandescent light source only. These can be

provided by your local electrical distributor, home center, or hardware store.


### **CLEANING**

Please clean with a soft, dry cloth ONLY! Do not use cleaning products.



# H457701S, H457701L SASHA PENDANT

# ASSEMBLYANDMOUNTINGDIAGRAM



## WIRE NUT/TAPINGDIAGRAM

